


How to Change Your Water Filters



Instructions:

1. Turn blue lever tap 45° to the left, to off position
2. Press black lever on faucet to remove any excess water from pipes
3. Remove one filter cartridge only at a time. To remove **Sediment Cartridge**, turn it to the left as far as you can then pull cartridge down to remove.
4. Replace Sediment Cartridge by inserting new cartridge and turning to the right until the cartridge locks into position. The **SEDIMENT CARTRIDGE MUST ALWAYS BE ON THE LEFT**
5. To remove and replace the **Carbon Cartridge**, repeat steps 3 and 4. The **CARBON CARTRIDGE MUST ALWAYS BE ON THE RIGHT.**
6. Attach new timer to filter cartridge. Timer will be activated when you press firmly to adhere the sticker to the cartridge.
7. Turn blue lever tap 45° to the right, to the on position
8. Press black lever tap on faucet and allow to flush out the new filter cartridges for 3-5 minutes before drinking.



For any enquiries, please call our Service Department 1300 787 905